



⚠ See Product Manual for complete installation and programming instructions.

1.0 Out-of-Box

1.1 Verify that you have received all of the parts listed



1.2 Download the product manual

Scan the QR code to open and download the product manual

- OR -

1. Go to www.vikingelectronics.com and enter **PA-250** in the search box
2. Under Documents click **Product Manual** to open and download the PDF



2.0 Features Overview



MIC: Microphone Input volume control and LED showing audio input level

ALC: Automatic Level Control adjustment for MIC and PAGE inputs

PAGE: Paging Input volume control and LED showing both activity and audio level

AUX: Auxiliary Input volume control and LED showing both activity and audio level

RING: Volume control and LED indicator for Chime and Loud Ringing tones


MUSIC: Volume control for Background Music Input

BASS: Low frequency tone control



TREBLE: High frequency tone control

MASTER VOLUME: Master volume control and LED level indicator for setting Peak Limiting

POWER: LED indicating power is on (winks off to indicate an overload condition)

 Use included slotted bit to adjust tamper resistant front panel pots.

3.0 Connections



SPEAKERS: Connect up to two hundred fifty (250) 70V or 25V speakers and/or paging horns

AC POWER INPUT: Connect to 100V to 240V AC power using the included "Y" power cord

- CHIME TRIG:** To trigger one of three different chime tones
- NIGHT TRANSFER:** To enable (open), or disable (closed) loud ringing
- RINGING LINE:** A ringing FXS or PABX analog station will trigger loud ringing
- BACKGROUND MUSIC INPUT:** 3.5mm jack for connecting music source
- 600 OHM OUTPUT:** Output for driving additional amplifiers
- SHIELD:** Analog ground
- AUX INPUT:** Auxiliary analog input
- PAGE CONTACT:** Contact closure input for telecom paging
- PAGE INPUT:** Analog input for telecom paging
- PROG:** Push button to access programming mode without security code
- FXO/FXS/PAGE PORT:** Slide switches for FXO (Loop Start), FXS (Ring Trip), or Page Port telecom paging
- PTT:** Push-to-Talk input for microphone
- MIC IN:** Low level dynamic microphone input

*See the Product Manual for complete installation and programming instructions.
 Questions? Call Viking Product Support: 715-386-8666*

Due to the dynamic nature of the product design, the information contained in this document is subject to change without notice. Viking Electronics, and its affiliates and/or subsidiaries assume no responsibility for errors and omissions contained in this information. Revisions of this document or new editions of it may be issued to incorporate such changes.